

STAINLESS ROTI COMBO

- Roasting pan with V-shaped rack
- Polished 18/10 stainless steel exterior and cooking surface
- Durable three-ply construction for years of use
- Compact pan is ideal for vegetables and chicken
- V-shaped rack cooks and browns evenly



Take home cooking beyond the ordinary with **All-Clad's Stainless Steel Roti Combo**, a roasting pan set that's ideal for vegetables and chicken. Like all All-Clad cookware, this roasting pan is crafted with premium stainless steel. The Roti Combo features classic style, ergonomic design, and durable construction for long-lasting performance. The set includes a nonstick V-shaped roasting rack

GOURMET ROASTER WITH V-SHAPED RACK

The included V-shaped nonstick roasting rack keeps food elevated to generate even cooking and browning. The pan's 2-3/4-inch-high sides reduce splattering, and the upright, riveted handles are easy to grasp when lifting. The Roti is also stovetop safe for cooking pan gravies after roasting. It measures 14" by 11" and is ergonomically designed for comfort.

PREMIUM STAINLESS STEEL CONSTRUCTION

Classic design, high performance, and lifetime durability unite in the Stainless Collection, All-Clad's most popular line of cookware. Products in the collection feature an interior core of aluminum for even heating and a high-polished, 18/10 stainless steel exterior and cooking surface for fine culinary performance. All-Clad stainless steel cookware features an interior starburst finish for excellent stick resistance. The bottom of each pan is engraved with a capacity marking for convenience.

CLEANING STAINLESS STEEL COOKWARE

All-Clad Stainless Steel cookware is designed for easy cleaning and a lifetime of use and is dishwasher safe.

- To avoid warping, never place a hot pan under cold water. Allow pan to cool prior to cleaning.
- For stainless steel surfaces, a non-abrasive and non-chlorine stainless steel cleanser is best.
- To clean the pan, immerse it in warm water. Form a paste with stainless steel cleanser and apply using a soft cloth. Rub in a circular motion from the center outwards. Wash in hot, soapy water and dry immediately to prevent water spotting.
- Nylon scrubbing pads can be used on the interior of All-Clad products. Use a sponge or soft cloth on exterior surfaces. Do not use oven cleaners, steel wool, steel scouring pads, harsh detergents, or detergents containing chlorine bleach.
- To prevent water spotting, after washing, rinse in hot water and dry immediately.